

MALCOP

ALQUILER Y VENTA DE MAQUINARIA


Genie®

Operator's Manual

with Maintenance Information

Sixth Edition
Second Printing
Part No. 1000209

Z™-60/34



DECALS

Inspection for Decals with Symbols

Determine whether the decals on your machine have words or symbols. Use the appropriate inspection to verify that all decals are legible and in place.



Part No.	Decal Description	Quantity
27204	Arrow - Blue	1
27205	Arrow - Yellow	1
27206	Triangle - Blue	2
27207	Triangle - Yellow	2
28158	Label - Unleaded	1
28159	Label - Diesel	1
28160	Label - Liquid Petroleum Gas (option)	1
28171	Label - No Smoking	1
28174	Label - Power to Platform, 230V	2
28235	Label - Power to Platform, 115V	2
32728	Label - Generator (option)	1
40434	Label - Lanyard Anchorage	3
44981	Label - Air Line to Platform (option)	2
52965	Cosmetic - Genie Z-60/34	1
52966	Cosmetic - 4 x 2	1
52967	Cosmetic - 4 x 4	1
52968	Cosmetic - Genie Boom	1
82238	Platform Control Panel	1
82544	Danger - Electrocution Hazard	2
82548	Warning - Platform Rotate	2

Part No.	Decal Description	Quantity
82472	Warning - Crushing Hazard	4
82473	Caution - Compartment Access	1
82487	Label - Read the Manual	2
82545	Danger - Maximum Capacity, 227 kg	1
82548	Warning - Platform Rotate	2
82589	Label - Tire Pressure	4
82671	Label - Weld Cable to Platform (option)	2
82602	Danger - Maximum Side Force, 667 N, ANSI	1
82604	Danger - Maximum Manual Force, 400 N, CE	1
82605	Warning - Collision Hazard	2
82606	Warning - Shear Point	2
82646	Label - Drive Enable Patch	1
82673	Ground Control Panel	1
82924	Caution - Component Damage	1
97815	Label - Lower Mid-rail	1
114166	Label -Transport Diagram	2
114244	Label - Wheel Load	4